

## TUFFLITE HANDLE REPLACEMENT

1. Disconnect throttle arm from trigger.
2. Remove Six T30 torque screws that hold upper and lower transmission cases together.
3. Replace old handle with new handle.
4. Put the two halves of the transmission back together and tighten six torque screws.
5. Take the wire and connect it to the throttle slide (make sure to put wire into the smaller of the two holes.)
6. Reconnect the throttle wire to the trigger.

